

Acrylic Clawfoot Assembly Guide

Follow all local plumbing and building codes while assembling our products.

Unpack and inspect your new feet for any shipping damages and ensure no pieces are missing.
If any damages are discovered DO NOT INSTALL.

Please contact customer service for assistance if needed @ (877)795-5684.

Before installation it is suggested to have a blanket or soft surface to avoid scratches while the tub is turned upside down during assembly.

Tools & Materials Needed

Included :

2 Brackets
4 Bolts
8 Washers
4 Nuts
4 Clawfeet

Required :

Socket Wrench
Sockets
17mm & 19mm

Suggested :

Soft Surface
2 people

Installation Preparation

Lay your soft surface down in the area of assembly
(Blanket, Carpet, etc)

Lay the bathtub upside down with the bolts on the bottom
pointed upwards.

Take the plastic caps off each of the bolts and remove the
nuts and washers.

These will be used for assembly so do not lose them.

1. Place a bracket down so that two bolts are placed in the center of the two elongated holes in the bracket. Hand tighten 1 washer and 1 nut onto each bolt ontop of the bracket.



2. Line the threaded hole in the end of the bracket with the hole on the back of a clawfoot to ensure it will fit properly. Adjust the bracket if needed.



3. After adjusting the bracket to the desired position, tighten the bracket down with a 17mm socket.



4. Using the supplied bolt & washers; attach the clawfeet to the bracket through the threaded hole on each end of the bracket.



5. Before fully tightening the clawfeet to the bracket with a 19mm socket, double check how the face of the clawfoot lays on the tub and make adjustments if needed.

Repeat Steps for each remaining bracket and clawfoot.

Use the adjustable leveler at the bottom of each foot to level the tub after assembly.

